
Frigoboat refrigeration system showing Cap Tube details



Evaporator shown is Flat (F) model, but instructions apply also to Bin (B) and Horizontal (H) models.

Recommended Procedure for Removing Moisture from System

- 1. Recover refrigerant
- 2. Evacuate system while applying heat to evaporator and tubing inside box
- 3. Run nitrogen through system
- 4. Repeat evacuation and heat process
- 5. Run nitrogen through system again
- 6. Add Filter/Drier, evacuate, and charge with refrigerant

