Philippi PSM Quick-Start Guide

(1) Note and record serial numbers and location/application of all devices connected to the network.

(2) Check all network and electrical connections. Install fuses only after all connections, polarity, etc., have been thoroughly checked.

(3) Press "Setup" tab on PSM Display. Enter "1234" as the password. Setup page is displayed.

(4) Press "Display" tab. Display Setup page 1 is displayed. Check that "PSM Address" is set to 0. (If other Displays are installed, they must be set to different address numbers. Setup is only configured on Display 0).

(5) Press forward arrow in top right hand corner. Page 2 of Display Setup is displayed.

(6) Press "Logged Devices". A list of logged devices should appear like this;

	Connect devices	
CMT VO	05, SN#999, ID=4	
CMT VO	05, SN#999, ID=5	
CMT VO	05, SN#999, ID=6	
CMT VO	05, SN#999, ID=7	
SHC 300	V016, SN#11, ID=0	
1. EM-bo	x -2 HW=2.0 SW=2.36, ID	=13
1. EM-bo	x -4 HW=2.0 SW=2.36, ID	=14
1. EM-bo	x -8 HW=2.0 SW=2.36, ID	=15
SHL 612	V016, SN#1125, ID=2	
SHL 612	V016, SN#1122, ID=3	

(7) Check that all devices are shown, and that serial numbers are correct.

NOTE: If any device is not shown, press the back arrow button on the top left corner to return to Display Setup page 2. Then press "Connect devices". Displayed screen should now show all connected devices. If a device(s) is still not shown, return to Display Setup page 2 and press "Renew device addresses". All devices should now be displayed. If any device is still not being shown, check and confirm power supply to the device and check network connections.

(8) Return to Setup screen, and set up the PSM Display and devices as described in Section 6 of the PSM Manual.

Coastal Climate Control, Inc. www.coastalcoolaids.com info@coastalcoolaids.com 301-352-5738 - Annapolis MD USA