

# Frigoboat

## Marine Refrigeration Systems

### Danfoss/Secop BD35 and BD50 Troubleshooting Guide

\*\*\*\*\*

***Answer the question below***

#### IS THE COMPRESSOR RUNNING?

NOTE: The compressors are virtually silent when running. Check compressor for vibration. Fan may be running even when compressor is not running. Disconnect the fan if necessary to assist troubleshooting.

#### IS THE COMPRESSOR RUNNING?

**YES**

Click link for: [Compressor IS Running Troubleshooting Guide](#)

**NO**

Click link for: [Compressor NOT Running Troubleshooting Guide](#)

\*\*\*\*\*

#### **Useful Information:**

- Refrigeration 101 [BLOG](#)
- Compressor Overview [VIDEO](#)
- Compressor Cutaway Inside View [VIDEO](#)
- Compressor Electrical Connections [VIDEO](#)
- So What Makes You Think Your Compressor is “Bad”? [pdf](#)
- Smart Speed Control SSC Replacement Guide [pdf](#)
- Frigoboat Couplings and O-Rings explained [VIDEO](#)



Coastal Climate Control, Inc.  
www.CoastalClimateControl.com - info@CoastalClimateControl.com  
301-352-5738 - Annapolis MD USA